




















Part No.	Chip Type	Color	Yield	For Use In	Picture reference
Sharp					
MX-18 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	13K	Sharp® MX-1800	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
MX-27 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	18k	Sharp® MX-1810/2000L/MX2300N/MX2700N	
	Toner Chip	●	15k	Sharp® MX-2000L/MX2300N/MX2700N; MX3500/MX4500/MX3501N/MX4501N	
	Toner Chip	●	15k		
	Toner Chip	●	15k		
MX-45 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	36k	Sharp® MX-3500/MX4500/MX3501N/MX4501N	
MX-31 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	18k	Sharp® MX2601N/3101N/2600N/3100N	
	Toner Chip	●	15k	Sharp® MX-2601N/3101N/2600N/3100N/MX-4101N/5001N/4100N/5000	
	Toner Chip	●	15k		
	Toner Chip	●	15k		
MX-50 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	36k	Sharp® MX-4101N/5001N/4100N/5000	
MX-70 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	42K	Sharp® MX-5500N/6200N/7000N	
	Toner Chip	●	36K	Sharp® MX-5500N/6200N/7000N/MX-M6201/7001	
	Toner Chip	●	36K		
	Toner Chip	●	36K		






MX-71 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	42K	Sharp® MX-M6201/7001	
MX-62 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	65K	Sharp® MX-6240N/7040(Under Testing)	
	Toner Chip	●	40K		
	Toner Chip	●	40K		
	Toner Chip	●	40K		
AR-C26 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	20K	Sharp® AR-BC260P/262/160/170/172/320	
	Toner Chip	●	11K		
	Toner Chip	●	11K		
	Toner Chip	●	11K		
MX-23 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	15K	Sharp® MX-2310U /MX-M2010/MX-M3111/MX-M2018UC/2318UC/3128/M2614/M3614/M2638/M3138	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
MX-36 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	24K	Sharp® MX-2610N/2615/3110N/M3140/M3610N/2618/3118/3618/M3640/M2615/M3115	
	Toner Chip	●	15K		
	Toner Chip	●	15K		
	Toner Chip	●	15K		
MX-51 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	40K	Sharp® MX-4110/4111/4140/4141//5110/5111/5140/5141/4112/5112/4128/5128	
	Toner Chip	●	18K		
	Toner Chip	●	18K		
	Toner Chip	●	18K		

MX-38 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	10K	Sharp® MX-C311/C380/381/C382	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
MX-C40 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	10K	Sharp® MX-C310/C312/C400/C401/C402	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
MX-235 CT	Toner Chip	●	16K	Sharp® AR-1808S/2008/2308	
MX-312 CT	Toner Chip	●	25K	Sharp® MX-M261/M311; AR-2608/3108/2628/3508	
MX-500 CT	Toner Chip	●		Sharp® MX-M283/M362/M363; MX-M452/M453/M503	
AR-203 ST-C	Toner Chip	●	16K	Sharp® AR-160N/201N/206N/163N; AR- 201N/N205/206N/M209N/1818/1820; AR-2616/2618/2620/2718; AR-2818/2820/2918/2921	
AR-021/022 ST-C	Toner Chip	●	16K	Sharp® AR-3020D/3818/3820/4818/4820	
AR-153 ST-C	Toner Chip	●	8K	Sharp® AR-158/158S/158F/158N	
AR-209 ST-C	Toner Chip	●	8K	Sharp® AR-208/208X/208N	

AR-311 ST-C	Toner Chip	●	25K	Sharp® AR-275/256L/316L/M318; AR-M258/M276/M236/255
AR-275 ST-C	Toner Chip	●	25K	Sharp® AR-M276/M236/255/275
AR-451 ST-C	Toner Chip	●	27K	Sharp® AR-M350/M450/M310U/M420U
AR-456 ST-C	Toner Chip	●	27K	Sharp® MX-M350N/M450N; AR-M351U/M451U/M351N/M451N
AR-622 ST-C	Toner Chip	●	83k	Sharp® MX-M550/MX620/MX700; AR-M550/M620/M700
AR-015/016 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	16K	Sharp® AR-5015//5020/5316E/5320E /5220/5120
AR-020/021 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	19K	Sharp® AR-5516/5520
AR-156 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	6K	Sharp® AR-121/151/156/157/168/ARF152
AR-202/201 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	15k	Sharp® AR- 162/162S/163/164/201/206/207/ARF201; ARM160/ARM162ARM205
AR-152/168 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	8K	Sharp® AR-122/152/5012/5415/AR- M150/M155
AR-208 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	8K	Sharp® AR-203E/AR208
AR-310 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	25K	Sharp® AR- 235/AR275/5127/ARM208/ARM236; ARM237/ARM257/ARM276/ARM277; ARM317ARN275
AR-270 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	25K	Sharp® 235/275/M236/M237; AR-M275/M276/M277/M208/M208N
AR-450 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	27K	Sharp® AR-M350/ARM450; AR-ARP350/ARP450/ARM280
AR-455 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	35K	Sharp® AR-M355/M455/MX- M350/M450.DM4551



AR-620 ET/FT/JT/LT/MT/NT/ST/T	Toner Chip	●	83k	Sharp® MX-550/MX620/MX700/MX720	
AR-266 JT	Toner Chip	●	25K	Sharp® AR-255/256/266/276	
AR-3511 ST	Toner Chip	●	27K	Sharp® AR-3511/4511	
AL-204TD(8K)/AL-214TD(4K)	Toner Chip	●	6K	Sharp® AL-2031/2041/2051/2061	
MX-206 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	16K	Sharp® M160/M160D/M200D/M181D/M211D	
MX-B20 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	8K	Sharp® MX-B200/B201;AR-2038	
MX-235 AT/BT/CT/FT/GT/JT/NT/X T	Toner Chip	●	16K	Sharp® AR-5618/5620/5623; MX-M182/M202/M232	
MX-312 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	25K	Sharp® MX-M260/M310/M264/M314/M354; AR-5726,AR-5627,AR-5731	
MX-500 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	40K	Sharp® M283/M362/M363/M452/M453/M503	
MX-B40 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●		Sharp® MX-B381/B400P/B401	
MX-B42 AT/BT/CT/FT/GT/JT/NT	Toner Chip	●	20K	Sharp® MX-B382/B402	

MX-560	Toner Chip	●		Sharp® M364/M365/M464/M465/M564/M565	MX-	
MX-753 NT/FT/JT/ST/AT/GT	Toner Chip	●	83K	MX-M623/M753		
MX-850 NT/FT/JT/ST/AT/GT	Toner Chip	●	120K	Sharp® MX-M850/950/1100M110		
MX-900 NT/FT/JT/ST/AT/GT	Toner Chip	●	120K	Sharp® MX-M904/MX-M1054/MX-M1204 (Under Development)		
DM-350DT	Toner Chip	●	27K	Sharp® DM3511		
DX-B35DTH	Toner Chip	●	18K	Sharp® Sharp DX-B350P Under Testing		
DX-B45DTH	Toner Chip	●	21K	Sharp® Sharp DX-B450P Under Testing		
DX-C40	Toner Chip	●	10K	Sharp® Sharp DX-C310/C311/C400/C401		
	Toner Chip	●	10K			
	Toner Chip	●	10K			
	Toner Chip	●	10K			
MX-6500	Toner Chip	●		Sharp® Sharp MX-6500/7500		
	Toner Chip	●				
	Toner Chip	●				
	Toner Chip	●				