





















Part No.	OEM Code		Color	Yield	Region	For Use In	
<b>XEROX Series</b>							
DocuPrint405	CT200425	Toner Chip	●	30K	JPN	Xerox® DocuPrint-405/505	
	CT350307	Drum Chip	●	60K	JPN		
DocuPrint5060	DocuPrint5060	Toner Chip	●	30K	JPN	Xerox® DocuPrint-5060/4060 JAPAN	
	CT350765	Drum Chip	●	57K	JPN		
Phaser-3100	106R01379	Toner Chip	●	4K	WW	Phaser-3100 Sim Card (NEW)	
Phaser-5550	113R00684	Toner Chip	●	35K	KOR	Phaser-5550	
	106R01294	Toner Chip	●	35K	EUR		
	113R00670	Drum Chip	●	60K	WW		
Phaser-7700	16188600	Drum Chip	●	24K	WW	Phaser-7700	
Phaser-7750	108R00582	Drum Chip	●	32K	WW	Phaser-7750	
DocuPrint C2250	CT201130	Toner Chip	●	15K	JPN	Xerox® DocuPrint C2250/C3360	
	CT201131	Toner Chip	●	12K			
	CT201132	Toner Chip	●	12K			
	CT201133	Toner Chip	●	12K			
	CT350615	Drum Chip	●●●●	40K			
DocuPrint C2250X	CT201133	Toner Chip	●	15K	KPN	Xerox® DocuPrint C2250/3360 MODEL-X	
	CT201134	Toner Chip	●	12K			
	CT201135	Toner Chip	●	12K			
	CT201136	Toner Chip	●	12K			
	CT201160	Toner Chip	●	15K			




DocuPrint C2255	CT201161	Toner Chip	●	12K	UNIVERSAL(EX JPN)	DocuPrint C2255	
	CT201162	Toner Chip	●	12K			
	CT201163	Toner Chip	●	12K			
	CT350654	Drum Chip	●●●●	40K			
DocuPrint C3350	CT201398	Toner Chip	●	5K	UNIVERSAL(EX JPN)	DocuPrint C3350(UNDER TESTING)	
	CT201399	Toner Chip	●	4.5K			
	CT201400	Toner Chip	●	4.5K			
	CT201401	Toner Chip	●	4.5K			
	CT350812	Drum Chip	●	24K			
	CT350813	Drum Chip	●●●	24K			
DocuPrint C5000	CT201688	Toner Chip	●	23K	JNP	DocuPrint C5000 d	
	CT201689	Toner Chip	●	12K			
	CT201690	Toner Chip	●	12K			
	CT201691	Toner Chip	●	12K			
DocuPrint C5005	CT201664	Toner Chip	●	26K	ASIA	DocuPrint C5005 d	
	CT201665	Toner Chip	●	25K			
	CT201666	Toner Chip	●	25K			
	CT201667	Toner Chip	●	25K			
	CT350894	Drum Chip	●●●●	70K			
DocuPrint CM505d	CT201680	Toner Chip	●	16K	ASIA	DocuPrint CM505d	
	CT201681	Toner Chip	●	12K			
	CT201682	Toner Chip	●	12K			
	CT201683	Toner Chip	●	12K			
	CT350889	Drum Chip	●	50K			
	CT350890	Drum Chip	●	50K			
	CT350891	Drum Chip	●	50K			
	CT350892	Drum Chip	●	50K			
	106R01506	Toner Chip	●	7.1K			
	106R01503	Toner Chip	●	5K			
	106R01504	Toner Chip	●	5K			

Phaser-6700	106R01505	Toner Chip	●	5K	North America,Western Europe	Phaser-6700(NEW)	
	106R01510	Toner Chip	●	18K			
	106R0157	Toner Chip	●	12K			
	106R0158	Toner Chip	●	12K			
	106R0159	Toner Chip	●	12K			
Phaser-6700	108R00974	DRUM CHIP	●	50K	WW	Phaser-6700(UNDER TESTING)	
	108R00971	DRUM CHIP	●	50K			
	108R00972	DRUM CHIP	●	50K			
	108R00973	DRUM CHIP	●	50K			
Phaser-7500	106R01433	Toner Chip	●	9.6K	EXP	Phaser-7500	
	106R01434	Toner Chip	●	9.6K			
	106R01435	Toner Chip	●	9.6K			
	106R01439	Toner Chip	●	19.8K			
	106R01436	Toner Chip	●	17.8K			
	106R01437	Toner Chip	●	17.8K			
	106R01438	Toner Chip	●	17.8K			
	106R01446	Toner Chip	●	17.8K	NON EXP		
	106R01443	Toner Chip	●	17.8K			
	106R01444	Toner Chip	●	17.8K			
	106R01445	Toner Chip	●	17.8K			
	106R00861	DRUM CHIP	●●●●	80K			
	Phaser-7760	106R01163	Toner Chip	●	32K		
106R01160		Toner Chip	●	25K			
106R01161		Toner Chip	●	25K			
106R01162		Toner Chip	●	25K			
108R00713		DRUM CHIP	●●●●	35K			
	106R01563	Toner Chip	●	6K			


Phaser-7800	106R01564	Toner Chip	●	6K	North America, Western Europe	Phaser-7800(UNDER TESTING)	
	106R01565	Toner Chip	●	6K			
	106R01569	Toner Chip	●	24K			
	106R01566	Toner Chip	●	17.2K			
	106R01567	Toner Chip	●	17.2K			
	106R01568	Toner Chip	●	17.2K			
	106R01569	DRUM CHIP	●●●●	24K	WW	Phaser-7800(UNDER TESTING)	
DocuCentre185	CT200397	Toner Chip	●	4K	JPN	DocuCentre-1055/1085/155/185	
	CT200653/CT200398	Toner Chip	●	9K	JPN		
DocuCentre186	CT200401	Toner Chip	●	10.8K	UNIVERSAL(EX JPN)	DocuCentre-156/186 DocuCentre 1055/1085	
	CT350285	Drum Chip	●	40K	UNIVERSAL(EX JPN)		
DocuCentre285	CT200414	Toner Chip	●	25K	JPN	DocuCentre-230/235/285/350/405(Japan)	
	CT350767/CT350593	Drum Chip	●	60K	JPN		
DocuCentre286	CT200417	Toner Chip	●	25K	UNIVERSAL(EX JPN)	DocuCentre-236/286/336 DocuCentre-II 2005/2055/3005 DC-III 2007/3007	
	CT350299/CT350769	Drum Chip	●	40K	UNIVERSAL(EX JPN)		
DocuCentre450i	CT200719	Toner Chip	●	25K	UNIVERSAL	ApeosPort 350 I/450 I/550 I ApeosPort-II 3000/4000/5010 DocuCentre450 I/550 I DocuCentre-II 4000/5010	
	CT350413	Drum Chip	●	85.5K	UNIVERSAL		
DocuCentre 6000	CT200943	Toner Chip	●	76K	KOR	DocuCentre-II6000/7000, ApeosPort-II6000/7000	
	CT350574	Drum Chip	●	352K			
WC 118	6R1179	Toner Chip	●	11K	UNIVERSAL	XER WC M118/C118	
WC 123	6R1182 (EU)	Toner Chip	●	30K	EUR	XEROX WC123/128/133	
	6R1184(EXP)	Toner Chip	●	30K	EXP	XEROX WC123/128/133	
WC 118	13R589	Drum Chip	●	60K	UNIVERSAL	C118/M118/M118I,C123/M123/WCP123,C128/M128/WCP128,C133/M133/WCP133	
XER 5500	113R00668	Toner Chip	●	30K	UNIVERSAL	XER 5500	
	113R00684	Toner Chip	●	30K	KOR		
	113R01294	Toner Chip	●	30K	EUR		
	113R00670	Drum Chip	●	60K	WW	XER 5500	



DocuCentre C400	CT350150	Drum Chip	●	36K	UNIVERSAL	DocuCentre C240/320/400	
DocuCentre C450	CT350352	Drum Chip	●	35K	UNIVERSAL	DocuCentre C250/350/450	
WorkCentre4150	006R01275	Toner Chip	●	20K	USA,Western Europe	WorkCentre 4150	
	006R01276	Toner Chip	●	20K	Mexico,South America Eastern		
	013R00623	Drum Chip	●	55K	UNIVERSAL		
WorkCentre5222	106R01413	Toner Chip	●	20K	South America Eastern	WorkCentre 5222/5225/5230	
	106R01306	Toner Chip	●	30K	North America Western		
	106R01305	Toner Chip	●	30K	South America Eastern		
	101R00434	Drum Chip	●	50K	EXP/EUR		
	101R00435	Drum Chip	●	80K	EXP/EUR		
WorkCentre M118	006R01179	Toner Chip	●	11K	EXP/EUR	WC M118	
	006R01184	Toner Chip	●	30K	EXP	WC M123/128/133	
	006R01182	Toner Chip	●	30K	EUR	WC M123/128/133	
	013R00589	Drum Chip	●	60K	EXP/EUR	WC M118/123/128/133	
WorkCentre 5325	006R01160	TONER CHIP	●	30K	South America, Middle East,Eastern Europe, Africa	WC 5325/5330/5335 (NEW)	
	UNIVERSAL	Drum Chip	●	96K	UNIVERSAL		
WorkCentre 4250	106R01410	Toner Chip	●	25K	South America Eastern	WorkCentre 4250/4260	
	106R01409	Toner Chip	●	25K	North America Western		
	113R00755	Drum Chip	●	80K	UNIVERSAL		
DocuCentre- III C2200	CT201213	Toner Chip	●	26K	UNIVERSAL(EX JPN)	DocuCentre-III C2200/C2205/C3300/C3305	
	CT201214	Toner Chip	●	15K			
	CT201215	Toner Chip	●	15K			
	CT201216	Toner Chip	●	15K			
	CT201102	Toner Chip	●	26K	JPN		
	CT201103	Toner Chip	●	15K			
	CT201104	Toner Chip	●	15K			
	CT201105	Toner Chip	●	15K			

	CT350748	Drum Chip	●●●●	91K	UNIVERSAL(EX JPN)		
	CT350595	Drum Chip	●●●●	91K	JPN		
DocuCentre-IV 2056	CT201795	Toner Chip	●	9K		DocuCentre-IV 2056/2058 (NEW)	
DocuCentre- IV2060	CT201734	Toner Chip	●	25K	UNIVERSAL(EX JPN)	DC-IV2060/3060/3065	
	CT350922	Drum Chip	●	55K	UNIVERSAL(EX JPN)		
DocuCentre-IV 2260	CT201434	Toner Chip	●	22K	UNIVERSAL(EX JPN)	DocuCentre-IV C2260/ C2263/ C2265	
	CT201435	Toner Chip	●	15K			
	CT201436	Toner Chip	●	15K			
	CT201437	Toner Chip	●	15K			
	CT201444	Toner Chip	●	22K	JPN	DocuCentre-IV C2260 (UNDER DEVELOPMENT)	
	CT201445	Toner Chip	●	15K			
	CT201446	Toner Chip	●	15K			
	CT201447	Toner Chip	●	15K			
	CT350819/CT350947	Drum Chip	●	53.7K	UNIVERSAL(EX JPN)	DocuCentre-IV C2260/ C2263/ C2265	
	CT350820/CT350948	Drum Chip	●				
	CT350821/CT350949	Drum Chip	●				
	CT350822/CT350950	Drum Chip	●				
	CT350823	Drum Chip	●	53.7K	JPN	DocuCentre-IV C2260 (UNDER DEVELOPMENT)	
	CT350824	Drum Chip	●				
CT350825	Drum Chip	●					
CT350826	Drum Chip	●					
	CT201370	Toner Chip	●	26K	UNIVERSAL(EX JPN)	DC- IV2270/2275/3370/3371/3373/3375/44 70/4475/5570/5575,ApeosPort- C2270/2275/3370/3371/3373/3375/447 0/4475/5570/5575	
	CT201371	Toner Chip	●	15K			
	CT201372	Toner Chip	●	15K			
	CT201373	Toner Chip	●	15K			
	CT201360	Toner Chip	●	26K			
	CT201361	Toner Chip	●	15K	JPN		

DocuCentre-IV2270	CT201362	Toner Chip	●	15K	JPN	DC-IV2270/2275/3370/3371/3373/3375/4470/4475/5570/5575,ApeosPort-C2270/2275/3370/3371/3373/3375/4470/4475/5570/5575  DC-IV C5570/C4470/C3370/C2270, AposPort-C5570/4470/3370/2270
	CT201363	Toner Chip	●	15K	UNIVERSAL(EX JPN)	
	CT350806	Drum Chip		103K		
	CT350851	Drum Chip	●●●●	150K	JPN	
	CT350804(LY)	Drum Chip		103K		
	CT350850(HY)	Drum Chip	●●●●	150K		
DocuCentre-IV 3070	CT201820	Toner Chip			DocuCentre-IV 3070/4070/5070, Apeosprot-IV 3070/4070/5070 (UNDER TESTING)	
	CT350942	Drum Chip	Color			
DocuCentre-IV4430	CT201676	Toner Chip	●	16K	UNIVERSAL(EX JPN)	DocuCentre-IV C4430
	CT201677	Toner Chip	●	12K		
	CT201678	Toner Chip	●	12K		
	CT201679	Toner Chip	●	12K		
	CT350895	Drum Chip	●	48K		
	CT350896	Drum Chip	●	48K		
	CT350897	Drum Chip	●	48K		
	CT350898	Drum Chip	●	48K		
DocuCentre-IV 7780	CT201586	Toner Chip	●	30K	KOR	DocuCentre IV-C5580/6680/7780(UNDER DEVELOPMENT)
	CT201587	Toner Chip	●	31.7K		
	CT201588	Toner Chip	●	31.7K		
	CT201589	Toner Chip	●	31.7K		
	CT350868	Drum Chip	●●●●			
DocuCentre-IV 7780	CT201582	Toner Chip	●	30K	JPN	DocuCentre IV-C5580/6680/7780(UNDER DEVELOPMENT)
	CT201583	Toner Chip	●	31.7K		
	CT201584	Toner Chip	●	31.7K		





















DocuCentre IV 7700	CT201585	Toner Chip	●	31.7K	JFIN	C300/3000/7700(UNDER DEVELOPMENT)	
	CT350865	Drum Chip	●●●●				
	CT350866	Drum Chip	●●●●				
DocuColor 240	006R01219	Toner Chip	●	30K	EXP	DocuColor 240/242/250/252/260/WorkCentre7655/ 7675	
	006R01222	Toner Chip	●	34K			
	006R01221	Toner Chip	●	34K			
	006R01220	Toner Chip	●	34K			
	006R01449	Toner Chip	●	30K	Western Europe		
	006R01452	Toner Chip	●	34K			
	006R01451	Toner Chip	●	34K			
	006R01450	Toner Chip	●	34K			
	006R90362	Toner Chip	●	30K	Eastern Europe, Asia, MiddleEast, Africa		
	006R90365	Toner Chip	●	34K			
	006R90364	Toner Chip	●	34K			
	006R90363	Toner Chip	●	34K			
	013R00602	Drum Chip	●	80K	EXP, EUR		DocuColor 240/242/250/252, WorkCentre7655/7675
	013R00603	Drum Chip	●●●●	115K			
DocuCentre II-3000, DocuCentre III3100/4100	CT200868	Toner Chip	●	21K	UNIVERSAL	DocuCentre II C3000, DocuCentre III C4100/ C3100	
	CT200869	Toner Chip	●	8K			
	CT200870	Toner Chip	●	8K			
	CT200870	Toner Chip	●	8K			
DocuCentre II-3000	CT350489	DRUM CHIP	●●●●	21K	UNIVERSAL	DocuCentre II C3000	
DocuCentre III3100	CT350737	DRUM CHIP	●●●●	22.1K	UNIVERSAL	DocuCentre III C4100/ C3100	
DocuColor 5000	006R01247	Toner Chip	●	22.5K	EXP	DocuColor 5000	
	006R01248	Toner Chip	●	37.5K			
	006R01249	Toner Chip	●	37.5K			
	006R01250	Toner Chip	●	37.5K			
DocuColor 7000/8000	006R01199	Toner Chip	●	25K	EXP	DocuColor 7000/8000	
	006R01200	Toner Chip	●	39K			
	006R01201	Toner Chip	●	39K			
	006R01202	Toner Chip	●	39K			
	CT200568	Toner Chip	●	25K			
	CT200569	Toner Chip	●	25K			


















Document Centre C6550	CT200570	Toner Chip	●	25K	ASIA except Japan	AposPort C5540/C6550/C7550, ApeosPort-II C5400/C6500/C7500, ApeosPort-III C5500/C6500/C7600,DocuColor 5065/5065 II/ 6075 II, DocuCenter C5540 I/C6550 I/ C7550 I, DocuCenter II C5400/C6500/C7500DocuCenter III C5500/C6500/C7600		
	CT200571	Toner Chip	●	25K				
	CT350361	DRUM CHIP	●	23.1K				
	CT350362	DRUM CHIP	●●●	10K				
	CT200564	Toner Chip	●	25K				
	CT200565	Toner Chip	●	25K	JPN			
	CT200566	Toner Chip	●	25K				
	CT200567	Toner Chip	●	25K				
	CT350359	DRUM CHIP	●	23.1K				
	CT350360	DRUM CHIP	●●●	10K				
WorkCentre 7120	006R01457	Toner Chip	●	22K	USA,Western Europe	WorkCentre 7120/7125		
	006R01460	Toner Chip	●	15K				
	006R01459	Toner Chip	●	15K				
	006R01458	Toner Chip	●	15K				
	006R01461	Toner Chip	●	22K	Mexico, South America,Eastern Europe, Middle East			
	006R01464	Toner Chip	●	15K				
	006R01463	Toner Chip	●	15K				
	006R01462	Toner Chip	●	15K				
	013R00657	DRUM CHIP	●	67K	UNIVERSAL			Xerox WorkCentre 7120/7125 (UNDER DEVELOPMENT)
	013R00660	DRUM CHIP	●	51K				
	013R00659	DRUM CHIP	●	51K				
	013R00658	DRUM CHIP	●	51K				
WorkCentre 7132	006R01317 (006R01319)	Toner Chip	●	24.3K	EUR	WorkCentre 7132/7232/7242		
	006R01265 (00R01273)	Toner Chip	●	8K				
	006R01264 (006R01272)	Toner Chip	●	8K				
	006R01263 (006R01271)	Toner Chip	●	8K				
	006R01318	Toner Chip	●	24.3K	USA			
	006R01269	Toner Chip	●	8K				
	006R01268	Toner Chip	●	8K				
	006R01267	Toner Chip	●	8K				
013R00636(CT350580)	Drum Chip	●●●●	80K	EXP/EUR				
	006R01395	Toner Chip	●	26K	USA Western Europe			
	006R01398	Toner Chip	●	15K				

WorkCentre 7425	006R01397	Toner Chip	●	15K	USA, western Europe	Xerox WorkCentre 7425/7428/7435	
	006R01396	Toner Chip	●	15K	Mexico, South America, Eastern Europe, Middle East		
	006R01399	Toner Chip	●	26K			
	006R01402	Toner Chip	●	15K			
	006R01401	Toner Chip	●	15K			
	006R01400	Toner Chip	●	15K			
	113R00647	Drum Chip	●●●●	61K	UNIVERSAL		
WorkCentre 7525	006R01513	Toner Chip	●	26K	USA, Western Europe	WC 7525/7530/7535/7545/7556	
	006R01516	Toner Chip	●	15K			
	006R01515	Toner Chip	●	15K			
	006R01514	Toner Chip	●	15K			
	006R01517	Toner Chip	●	26K	Mexico, South America, Eastern Europe, Middle East		
	006R01520	Toner Chip	●	15K			
	006R01519	Toner Chip	●	15K			
	006R01518	Toner Chip	●	15K			
013R00662	Drum Chip	●●●●	61K	UNIVERSAL			
WorkCentre 7755	006R01403	Toner Chip	●	30K	South America, Middle East, Eastern Europe, Africa	WorkCentre 7755/7765/7775 (UNDER TESTING)	
	006R01404	Toner Chip	●	34K			
	006R01405	Toner Chip	●	34K			
	006R01406	Toner Chip	●	34K			
WorkCentre-5019	013R00670	Drum Chip	●	80K	South America Eastern Europe / Africa	WorkCentre-5019	
XER WC1080/2000/2003		Drum Chip	●	21K	UNIVERSAL	XER WC1080/2000/2003	
XER WC5016/5020	101R00432、101R432	Drum Chip	●	22K	UNIVERSAL	XER WC5016/5020	
PHASER 6121BK	106R1469	Toner Chip	●	2.6K	WW	XEROX PHASER 6121(四色通用)	
PHASER 6121C	106R1468	Toner Chip	●	2.6K			
PHASER 6121 M	106R1467	Toner Chip	●	2.6K			
PHASER 6121 Y	106R1466	Toner Chip	●	2.6K			
PHASER 6120	113R00692	Toner Chip	●	4.5K	WW	Phaser 6120/6115	
	113R00693	Toner Chip	●	4.5K			






























PHASER 6120	113R00694	Toner Chip	●	4.5K	VVV		
	113R00695	Toner Chip	●	4.5K			
Phaser 6280	106R01395	Toner Chip	●	7K	WW	Xerox Phaser 6280	
	106R01392	Toner Chip	●	5.9K			
	106R01393	Toner Chip	●	5.9K			
	106R01394	Toner Chip	●	5.9K			
docuprintC2200		Toner Chip	●	9K	WW	Fuji-Xerox docuprintC2200/C3300	
		Toner Chip	●	9K			
		Toner Chip	●	9K			
		Toner Chip	●	9K			
6180 TK	113R00726	Toner Chip	●	8K	WW	XER 6180	
6180 TC	113R00723	Toner Chip	●	6K			
6180 TM	113R00724	Toner Chip	●	6K			
6180 TY	113R00725	Toner Chip	●	6K			
6250 TK	106R00675	Toner Chip	●	8K	WW	XER 6250	
6250 TC	106R00672	Toner Chip	●	8K			
6250 TM	106R00673	Toner Chip	●	8K			
6250 TY	106R00674	Toner Chip	●	8K			
6300 TK	106R01085	Toner Chip	●	7K	WW	XER 6300	
6300 TC	106R01082	Toner Chip	●	7K			
6300 TM	106R01083	Toner Chip	●	7K			
6300 TY	106R01084	Toner Chip	●	7K			
6350 TK	106R01147	Toner Chip	●	10K	WW	XER 6350	
6350 TC	106R01144	Toner Chip	●	10K			
6350 TM	106R01145	Toner Chip	●	10K			
6350 TY	106R01146	Toner Chip	●	10K			
6360 TK	106R01221	Toner Chip	●	9K/18K	WW	XER 6360	
6360 TC	106R01218	Toner Chip	●	5K/12K			


6360 TM	106R01219	Toner Chip	●	5K/12K	WWW	XER 0300	
6360 TY	106R01220	Toner Chip	●	5K/12K			
C2100 TK	CT350504	Toner Chip	●	8K	WW	FUJI XER DOCUPRINT C2100/3210	
C2100 TC	CT350505	Toner Chip	●	6K			
C2100 TM	CT350506	Toner Chip	●	6K			
C2100 TY	CT350507	Toner Chip	●	6K			
DCP3200 K	C7200710	Toner Chip	●	3k			
DCP3200 C	C7200711	Toner Chip	●	3k	WW	Xerox DocuPrint C3200	
DCP3200 M	C7200712	Toner Chip	●	3k			
DCP3200 Y	C7200713	Toner Chip	●	3k			
C3290 TK	CT350567	Toner Chip	●	8K			
C3290 TC	CT350568	Toner Chip	●	6K	WW	FUJI XER DOCUPRINT C3290	
C3290 TM	CT350569	Toner Chip	●	6K			
C3290 TY	CT350570	Toner Chip	●	6K			
C2535 TK	CT200655	Toner Chip	●	9K			
C2535 TC	CT200656	Toner Chip	●	8K	WW	FUJI XER C2535A	
C2535 TM	CT200657	Toner Chip	●	8K			
C2535 TY	CT200658	Toner Chip	●	8K			
C525A TK	CT200649	Toner Chip	●	4K			
C525A TC	CT200652	Toner Chip	●	4K	JNP	FUJI XER C525A/C2090	
C525A TM	CT200651	Toner Chip	●	4K			
C525A TY	CT200650	Toner Chip	●	4K			
C525A DRUM	CT350390	Drum Chip	●	6.5K			
C3050 BK	CT200822	Toner Chip	●	6.5K			
C3050 C	CT200823	Toner Chip	●	6.5K	WW	Xerox DocuPrint C3050	
C3050 M	CT200824	Toner Chip	●	6.5K			
C3050 Y	CT200825	Toner Chip	●				
C3050 Drum		Drum Chip					
XEROX CP105 BK	CT201595	Toner Chip	●	2K			
XEROX CP105 C	CT201596	Toner Chip	●	1.4K			

XEROX CP105 M	CT201597	Toner Chip	●	1.4K	ASIA	XEROX DocuPrint CP 100/200 CM200	
XEROX CP105 Y	CT201598	Toner Chip	●	1.4K			
XEROX CP100 BK	CT201757	Toner Chip	●	0.7K			
XEROX CP100 C	CT201758	Toner Chip	●	0.7K			
XEROX CP100 M	CT201759	Toner Chip	●	0.7K			
XEROX CP100 Y	CT201760	Toner Chip	●	0.7K			
XEROX CP100 BK	CT201761	Toner Chip	●	2K	JPN	Xerox DocuPrint CP100b/cp200w/CM200fw	
XEROX CP100 C	CT201762	Toner Chip	●	1.4K			
XEROX CP100 M	CT201763	Toner Chip	●	1.4K			
XEROX CP100 Y	CT201764	Toner Chip	●	1.4K			
XEROX M200	CT201779	Toner Chip	●	2.2K	JPN	Xerox DocuPrint M200 fw / P200 b	
	CT201778	Toner Chip	●	1K			
DocuPrint P255dw	CT201918	Toner Chip	●	2.5K	ASIA	DocuPrint P255dw/M255z	
DocuPrint P205	CT201609	Toner Chip	●	1K	ASIA	DocuPrint P205/M205	
	CT201610	Toner Chip	●	2.2K			
DocuPrint CP305	CT201632	Toner Chip	●	3K	ASIA	DocuPrint CP305/CM305MF	
	CT201633	Toner Chip	●	3K			
	CT201634	Toner Chip	●	3K			
	CT201635	Toner Chip	●	3K			
CP405d BK	CT202033	Toner Chip	●	11K	ASIA	 DocuPrint CP405d/CM405MF	
CP405d C	CT202034	Toner Chip	●	11K			
CP405d M	CT202035	Toner Chip	●	11K			
CP405d Y	CT202036	Toner Chip	●	11K			
CP405d BK	CT202018	Toner Chip	●	7K			
CP405d C	CT202019	Toner Chip	●	5K			
CP405d M	CT202020	Toner Chip	●	5K			
CP405d Y	CT202021	Toner Chip	●	5K			
DPP 450	CT202078	Toner Chip	●	12.5K			
C1110	CT201118	Toner Chip	●	2K	WW	Xerox® Docuprint C1110/1110B	
	CT201119	Toner Chip	●	2K			
	CT201120	Toner Chip	●	2K			


	CT201121	Toner Chip	●	2K				
Phaser 6125	106R01334	Toner Chip	●	2K	North America	Phaser 6125		
	106R01331	Toner Chip	●	1K				Western Europe
	106R01332	Toner Chip	●	1K				
	106R01333	Toner Chip	●	1K	Africa			
	106R01338	Toner Chip	●	2K				South America
	106R01335	Toner Chip	●	1K				
	106R01336	Toner Chip	●	1K	Eastern Europe			
	106R01337	Toner Chip	●	1K				
	Phaser 6128MFP	106R01455	Toner Chip	●	3.1K			North America
106R01452		Toner Chip	●	2.5K	Western Europe			
106R01453		Toner Chip	●	2.5K				
106R01454		Toner Chip	●	2.5K		Africa		
106R01459		Toner Chip	●	3.1K	South America			
106R01456		Toner Chip	●	2.5K				
106R01457		Toner Chip	●	2.5K	Eastern Europe			
106R01458		Toner Chip	●	2.5K				
Phaser 6130	106R01281	Toner Chip	●	2.5K	North America	Phaser 6130		
	106R01278	Toner Chip	●	1.9K				Western Europe
	106R01279	Toner Chip	●	1.9K				
	106R01280	Toner Chip	●	1.9K	Africa			
	106R01285	Toner Chip	●	2.5K				South America
	106R01282	Toner Chip	●	1.9K				
	106R01283	Toner Chip	●	1.9K	Eastern Europe			
	106R01284	Toner Chip	●	1.9K				
Phaser 6140	106R01480	Toner Chip	●	2.6K	North America	Phaser 6140		
	106R01477	Toner Chip	●	2K				Western Europe
	106R01478	Toner Chip	●	2K				
	106R01479	Toner Chip	●	2K	Africa			
	106R01484	Toner Chip	●	2.6K				





	106R01481	Toner Chip		2K	South America Eastern Europe	SCC25A	
	106R01482	Toner Chip		2K			
	106R01483	Toner Chip		2K			
DocuPrint P105	CT201613	Toner Chip		2.2K	ASIA	 DocuPrint P105/P158b/M158b/M158ab/M158f	
DocuPrint P455d	CT201949	Toner Chip		25K	ASIA	DocuPrint P455d	
DocuPrint P355d	CT201937	Toner Chip		4K	ASIA	Xerox DocuPrint P355d/M355df	
	CT201938	Toner Chip		10K			
Phaser 3010	106R02180	Toner Chip		1K	Universal	Phaser 3010/3040;WorkCentre 3045	
	106R02182	Toner Chip		1.2K	Belarus / India		
	106R02181	Toner Chip		1K			
	106R02183	Toner Chip		1.2K			
Phaser 6000	106R01630	Toner Chip		2K	North America	Phaser 6000 /6010;WorkCentre 6015	
	106R01627	Toner Chip		1K	Western Europe		
	106R01628	Toner Chip		1K			
	106R01629	Toner Chip		1K			
	106R01634	Toner Chip		2K	Africa		
	106R01631	Toner Chip		1K	South America		
	106R01632	Toner Chip		1K	Eastern Europe		
	106R01633	Toner Chip		1K			
	106R01597	Toner Chip		3K			
	Phaser 6500	106R01594	Toner Chip		2.5K		North America
106R01595		Toner Chip		2.5K			
106R01596		Toner Chip		2.5K			
106R01591		Toner Chip		1K	Western Europe		
106R01592		Toner Chip		1K			
106R01593		Toner Chip		1K			
		106R01604	Toner Chip		3K	Africa	
		106R01601	Toner Chip		2.5K		






	106R01602	Toner Chip	●	2.5K	Africa		
	106R01603	Toner Chip	●	2.5K	South America		
	106R01598	Toner Chip	●	1K	Eastern Europe		
	106R01599	Toner Chip	●	1K			
	106R01500	Toner Chip	●	1K			
XEROX 6600	106R02228	Toner Chip	●	8K	North America	Phaser 6600;WorkCentre 6605NF(Coming Soon)	
	106R02225	Toner Chip	●	6K			
	106R02226	Toner Chip	●	6K			
	106R02227	Toner Chip	●	6K			
	106R02244	Toner Chip	●	3K			
	106R02241	Toner Chip	●	2K			
	106R02242	Toner Chip	●	2K			
	106R02243	Toner Chip	●	2K	Western Europe		
	106R02232	Toner Chip	●	8K			
	106R02229	Toner Chip	●	6K			
	106R02230	Toner Chip	●	6K			
	106R02231	Toner Chip	●	6K			
	106R02248	Toner Chip	●	3K			
	106R02245	Toner Chip	●	2K			
	106R02246	Toner Chip	●	2K	Africa South America Eastern Europe		
	106R02247	Toner Chip	●	2K			
	106R02236	Toner Chip	●	8K			
	106R02233	Toner Chip	●	6K			
	106R02234	Toner Chip	●	6K			
	106R02235	Toner Chip	●	6K			
	106R02252	Toner Chip	●	3K			
	106R02249	Toner Chip	●	2K			
	106R02250	Toner Chip	●	2K			
106R02251	Toner Chip	●	2K				
	106R02605	Toner Chip	●	10K			

Phaser 7100	106R02602	Toner Chip	●	9K	North America Western Europe	Phaser 7100(Coming Soon.....)	
	106R02603	Toner Chip	●	9K			
	106R02604	Toner Chip	●	9K			
	106R02599	Toner Chip	●	4.5K			
	106R02600	Toner Chip	●	4.5K			
	106R02601	Toner Chip	●	4.5K			
	106R02612	Toner Chip	●	10K	Africa South America Eastern Europe		
	106R02609	Toner Chip	●	9K			
	106R02610	Toner Chip	●	9K			
	106R02611	Toner Chip	●	9K			
	106R02606	Toner Chip	●	4.5K			
	106R02607	Toner Chip	●	4.5K			
	106R02608	Toner Chip	●	4.5K			
	106R01316	Toner Chip	●	12K			
106R01317	Toner Chip	●	16.5K				
106R01318	Toner Chip	●	16.5K				
106R01319	Toner Chip	●	16.5				
106R01320	Toner Chip	●	8K				
106R01321	Toner Chip	●	8K				
106R01322	Toner Chip	●	8K				
108R00774	Drum Chip	●	30K				
108R00775	Drum Chip	●	30K				
108R00776	Drum Chip	●	30K				
108R00777	Drum Chip	●	30K				
XEROX 4050	CT350761	Toner Chip	●			Xerox 4050	
XEROX 4500L		Toner Chip	●	10K		Xerox Phaser 4500 series	
XEROX 4500H	113R00657	Toner Chip	●	18K			
XEROX 4510H	113R00712	Toner Chip	●	19K	113R00712	Xerox Phaser 4510 series	
XEROX 5400	113R00495	Toner Chip	●	20K		Xerox Phaser 5400	
XEROX DCP360JP	CT350051	Toner Chip	●	20K	JPN	Xerox DocuPrint 360	

DocuPrint205	CT350251	Toner Chip	●	10K	UNIVERSAL(EX JPN)	Xerox® DP-202/205/255/305
	CT350245	Toner Chip	●	10K	JPN	
DocuPrint240	CT350268	Toner Chip	●	10K	UNIVERSAL(EX JPN)	Xerox® DP-240/340
XER XL5900		Toner Chip	●	10K	JPN	FUJI XL5900/XL5400/XL5370/XL5770
PE120	013R00601	Toner Chip	●	3.5K	WW	Xerox® Pe120/Pe120i
	013R00606	Toner Chip	●	5K	WW	
Phaser 3150	109R00746	Toner Chip	●	3.5K	WW	Xerox® Phaser 3150B
	109R00747	Toner Chip	●	5K	WW	
Phaser 3450	106R00687	Toner Chip	●	5K	WW	Xerox® Phaser 3450B
	106R00688	Toner Chip	●	10K	WW	
Phaser 3119	013R00625	Toner Chip	●	3K	WW	Xerox® Phaser 3119
Phaser 3420	106R01033	Toner Chip	●	5K	WW	Xerox® Phaser 3420
	106R01034	Toner Chip	●	10K	WW	
Phaser 3500	106R01148	Toner Chip	●	6K	WW	Xerox® Phaser 3500
	106R01149	Toner Chip	●	12K	WW	
WorkCentre 4118	006R01278	Toner Chip	●	8K	WW	Xerox® WorkCentre 4118
WorkCentre M-20/20i	106R01047	Toner Chip	●	8K	WW	Xerox® WorkCentre M-20/20i
PE220	013R00621	Toner Chip	●	3K	WW	Xerox® WorkCentre PE220
3200mfp	113R00730	Toner Chip	●	3K	WW	Xerox® 3200mfp
Phaser 3635MFP	108R00793	Toner Chip	●	5K	EXP	Xerox® Phaser 3635MFP
	108R00795	Toner Chip	●	10K	EXP	
	108R00796	Toner Chip	●	10K	ME	
Phaser 3478	106R01245	Toner Chip	●	4K	WW	Xerox® Phaser 3478D/3478DN



Phaser 3420	106R01246	Toner Chip	●	8K	WW	XEROX® PHASER 3420D/3420DN	
Phaser 3300	106R01411	Toner Chip	●	4K	WW	Xerox® Phaser 3300	
	106R01412	Toner Chip	●	8K	WW		
3435MFP	106R01414	Toner Chip	●	4K	WW	Xerox® 3435MFP	
	106R01415	Toner Chip	●	10K	WW		
Phaser 3600	106R01370	Toner Chip	●	7K	EXP	Xerox® Phaser 3600N/3600DN	
	106R01371	Toner Chip	●	14K	EXP		
Xerox® 3250	106R01373	Toner Chip	●	3.5K	WW	Xerox® 3250	
	106R01374	Toner Chip	●	5K	WW		
Phaser 6110	106R01274	Toner Chip	●	2K	WW	Xerox® Phaser 6110/6110mfp	
	106R01271	Toner Chip	●	1K	WW		
	106R01272	Toner Chip	●	1K	WW		
	106R01273	Toner Chip	●	1K	WW		