



















Part No.	Chip Type	Color	Yield	For Use In	Picture reference
<b>Sharp</b>					
MX-561	Toner Chip	●	40K	Sharp® MX-M3050;MX-M3070;MX-M3570;MX-M4050;MX-M4070;MX-M5050;MX-M5070;MX-M6050;MX-M6070;MX-M364N;MX-M365N;MX-M464N;MX-M465N;MX-M564N;MX-M565N(Under Testing)	
MX-B45	Toner Chip	●	30K	Sharp® MX-B355W;MX-B455W(Under Testing)	
DX-C20TB	Toner Chip	●	6.5K	Sharp® DX-C200/C200P	
DX-C20TC	Toner Chip	●	6K		
DX-C20TM	Toner Chip	●	6K		
DX-C20TY	Toner Chip	●	6K		
MX-60	Toner Chip	●	40K	Sharp® MX-3050N, MX-3060;MX-3070N, MX-MX-3060;MX3550N, MX-3570N, MX-4050N, MX-4060; MX-4070N, MX-5050N, MX-5070N, MX-6050N, MX-6070N	
	Toner Chip	●	24K		
	Toner Chip	●	24K		
	Toner Chip	●	24K		
DX-25	Toner Chip	●	20K	Sharp® DX-2508NC/2008UC/DX2500	
	Toner Chip	●	7K		
	Toner Chip	●	7K		
	Toner Chip	●	7K		
MX-18	Toner Chip	●	13K	Sharp® MX-1800	
	Toner Chip	●	10K		
	Toner Chip	●	10K		





	Toner Chip	●	10K		
MX-27	Toner Chip	●	18k	Sharp® MX-2000L MX-2300N MX-2700N	
	Toner Chip	●	15k	Sharp® MX-2000L/MX2300N/MX2700N; MX3500/MX4500/MX3501N/MX4501N	
	Toner Chip	●	15k		
	Toner Chip	●	15k		
MX-45	Toner Chip	●	36k	Sharp® MX-3500/MX4500/MX3501N/MX4501N	
MX-31	Toner Chip	●	18k	Sharp® MX2601N/3101N/2600N/3100N	
	Toner Chip	●	15k	Sharp® MX-2601N/3101N/2600N/3100N/MX-4101N/5001N/4100N/5000	
	Toner Chip	●	15k		
	Toner Chip	●	15k		
MX-50	Toner Chip	●	36k	Sharp® MX-4101N/5001N/4100N/5000	
MX-70	Toner Chip	●	42K	Sharp® MX-5500N/6200N/7000N	
	Toner Chip	●	36K	Sharp® MX-5500N/6200N/7000N/MX-M6201/7001	
	Toner Chip	●	36K		
	Toner Chip	●	36K		
MX-71	Toner Chip	●	42K	Sharp® MX-M6201/7001	
MX-62	Toner Chip	●	65K	Sharp® MX-6240N/7040/6500/7500	
	Toner Chip	●	40K		
	Toner Chip	●	40K		
	Toner Chip	●	40K		
	Toner Chip	●	60K		




MX-75	Toner Chip	●	60K	Sharp® MX-6500/7500(Under Testing)	
	Toner Chip	●	60K		
AR-C26	Toner Chip	●	20K	Sharp® AR-BC260P/262/160/170/172/320	
	Toner Chip	●	11K		
	Toner Chip	●	11K		
	Toner Chip	●	11K		
MX-23	Toner Chip	●	15K	Sharp® MX-1810;MX-2310U /MX-M2010/MX-M3111、 3114/3115/2616/3116;MX-M2018UC/2318/2338/3128/3618/M2614/M3614/M2638/M3138	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
MX-36	Toner Chip	●	24K	Sharp® MX-2610N/2615/2616/3110N/M3140/M3610N/2618/3118/3618/M3640/M2615/M3115/2515	
	Toner Chip	●	15K		
	Toner Chip	●	15K		
	Toner Chip	●	15K		
MX-51	Toner Chip	●	40K	Sharp® MX-4110/4111/4140/4141//5110/5111/5140/5141/4112/5112/4128/5128/MX-5148NC/4148NC	
	Toner Chip	●	18K		
	Toner Chip	●	18K		
	Toner Chip	●	18K		
MX-C38	Toner Chip	●	10K	Sharp® MX-C311/C312/C380/C381/C382	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		

DX-C38	Toner Chip	●	10K	Sharp® DX-C310/C311/C312/C380/C381	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
MX-C40	Toner Chip	●	10K	Sharp® MX-C310/C311/C312/C400/C401/C402	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
DX-C40	Toner Chip	●	10K	Sharp® Sharp DX-C310/C311/C400/C401	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
MX-C30	Toner Chip	●	10K	Sharp® Sharp MX-C250;MX-C300P; MX-C300W; MX-C301W	
	Toner Chip	●	10K		
	Toner Chip	●	10K		
	Toner Chip	●	10K		
AR-015/016	Toner Chip	●	16K	Sharp® AR-5015//5020/5316E/5320E /5220/5120	
AR-020/021	Toner Chip	●	19K	Sharp® AR-5516/5520	
AR-156	Toner Chip	●	8K	Sharp® AR-121/151/152/156	
AR-202/201	Toner Chip	●	15k	Sharp® AR-162/162S/163/164/165/201/206/207/ARF201 ; ARM160/ARM162ARM205	
AR-168	Toner Chip	●	8K	Sharp® AR-122/152/153/157/168/5012/5415/AR-M150/M155	
AR-208	Toner Chip	●	8K	Sharp® AR-203E/AR208	
AR-270	Toner Chip	●	25K	Sharp® AR-235/275/M236/M237; AR-M275/M276/M277/M208/M208N	

AR-310	Toner Chip	●	25K	Sharp® AR-235/AR275/5127/ARM208/ARM236; ARM237/ARM257/ARM276/ARM277; ARM317ARN275	
AR-450	Toner Chip	●	27K	Sharp® AR-M350/ARM450; AR-ARP350/ARP450/ARM280	
AR-455	Toner Chip	●	35K	Sharp® AR-M355/M455/MX-M350/M450.DM4551;AR-M351/M451	
AR-620	Toner Chip	●	83k	Sharp® AR-M550/620/700;MX-M550/MX620/MX700/MX720	
MX-753	Toner Chip	●	83K	Sharp® MX-M623/M753	
MX-754	Toner Chip	●	83K	Sharp® MX-M654/M754	
MX-850	Toner Chip	●	120K	Sharp® MX-M850/950/1100M110/1055	
MX-900	Toner Chip	●	120K	Sharp® MX-M904; MX-M905;MX-M1054;MX-M1055;MX-M1204;MX-M1205	
AL-204TD(8K)/A L-214TD(4K)	Toner Chip	●	6K	Sharp® AL-2031/2041/2051/2061	
MX-206	Toner Chip	●	16K	Sharp® MX-M160/M160D/M200D/M181D/M211D	

MX-B20	Toner Chip	●	8K	Sharp® MX-B200/B201;AR-2038	
MX-235	Toner Chip	●	16K	Sharp® AR-5618, AR-5620, AR-5623, MX-M182D, MX-M202D, MX-M232D	
MX-237	Toner Chip	●	20K	Sharp® AR-6018D/6020D/6023D/6026N/6031N	
MX-312	Toner Chip	●	25K	Sharp® MX-M260/M310/M264/M314/M354; AR-5726,AR-5627,AR-5731	
MX-315	Toner Chip	●	27.5K	Sharp® MX-M265;MX-M266N, MX-M316N;MX-M356	
MX-500	Toner Chip	●	40K	Sharp® MX-M283/M362/M363/M452/M453/M503	
MX-560	Toner Chip	●	40K	Sharp® MX-M364/M365/M464/M465/M564/M565	
MX-B40	Toner Chip	●	10K	Sharp® MX-B381/B400P/B401	
MX-B42	Toner Chip	●	20K	Sharp® MX-B382/B402	
DX-B35DTH	Toner Chip	●	18K	Sharp® Sharp DX-B350P Under Testing	
DX-B45DTH	Toner Chip	●	21K	Sharp® Sharp DX-B450P Under Testing	
AM-330	Toner Chip	●	3K	Sharp® AM300/330	
MX61JTBA	Toner Chip	●	30K	MX-6170FN / MX-6150FN / MX-5170FN / MX-5150FN / MX-4170FN / MX-4150FN /	
MX61JTCA	Toner Chip	●	20K		

MX61JTMA	Toner Chip	●	20K	MX-3150FN / MX-3170FN / MX-3150FN / MX-3650FN / MX-3150FN / MX-2650FN	
MX61JTYA	Toner Chip	●	20K		
AR-ST47-B	Toner Chip	●	20K	AR-255F AR-255FP AR-255P AR-255S AR-265FG AR-265FP AR-265G AR- 265S AR-266FG AR-266FP AR-266G AR-266S AR-267FG AR-267FP AR- 267G AR-267S AR-317FG AR-317FP AR-317G AR-317S	
AR-ST48-B	Toner Chip	●	10K		
AR-ST33-B	Toner Chip	●	20K	AR-310F AR-310M AR-310S AR-312S AR-350F AR-350LP AR-350M AR-350S AR-420S AR-450F AR-450LP AR-450M AR-450S	
AR-ST36-B	Toner Chip	●	10K		
AR-ST44-B	Toner Chip	●	20K	AR-311FP AR-311N AR-311S AR- 351FP AR-351N AR-351S AR-451FP AR-451N AR-451S	
AR-ST45-B	Toner Chip	●	50K	AR-555S AR-625S AR-705S	
AR-ST48-B; AR-ST29-B	Toner Chip	●	10K	AR-255S;AR-255P;AR-255F;AR-255FP;AR- 265S;AR-265G;AR-265FG;AR-265FP;AR- 266S;AR-266G;AR-266FG;AR-266FP;AR- 267S;AR-267G;AR-267FG;AR-267FP;AR- 317S;AR-317G;AR-317FG;AR-317FP	
AR-ST47-B; AR-ST28-B	Toner Chip	●	20K		
AR-CK31-BN	Toner Chip	●	10K	AR-141G AR-160M AR-163 AR-163G AR-200M AR-161 AR-205 AR- F163FGN AR-F201 AR-S140 AR-162 AR-S201 AR-S206 AR-163FG AR-201 AR-F201P AR-161P AR-F161 AR- F161P AR-S161 AR-163F AR-S162 AR-163FGN AR-163GN AR-205FGN AR-205G AR-205GN AR-S201Y	
AR-CK32-BN	Toner Chip	●	5K		
AR-CK31-BN	Toner Chip	●	10K	AR-141G AR-160M AR-163 AR-163G AR-200M AR-161 AR-205 AR- F163FGN AR-F201 AR-S140 AR-162 AR-S201 AR-S206 AR-163FG AR-201 AR-F201P AR-161P AR-F161 AR- F161P AR-S161 AR-163F AR-S162 AR-163FGN AR-163GN AR-205FGN AR-205G AR-205GN AR-S201Y	
AR-CK32-BN	Toner Chip	●	5K		

AR-CK49-B	Toner Chip	●	10K	AR-N161G AR-N161FG AR-N201G AR-N201FG AR-164G	
AR-CK50-B	Toner Chip	●	5K		
AR-CK52-B	Toner Chip	●	5K	AR-N181G AR-N182G AR-N182FG	
AR-CK51-B	Toner Chip	●	10K		
AR-CK53-B	Toner Chip	●	5K	AR-N202FP	

NT 北美

T/LT/GT 欧洲, 澳洲

BT/MT 南美

ST/AT 东南亚, 香港, 除菲律宾, 除中国台湾地区

FT/ET/XT |, 菲律宾, 中国台湾地区

ST-C/CT 中国大陆

JT 日本







0





0.436893







